

Standard Water

"EC" Series Electric Humidifier

The "EC" Series Electric Humidifier from PURE Humidifier Co. is loaded with features and options. All you need is tap water, electricity, and a sanitary drain. The humidifier does the rest.

These units feature a Tri-Probe electronic water level control system made up of three Teflon® coated stainless steel probes. The lower probe prevents the heating elements from energizing when the water level is too low. The middle probe electrically activates the water control valve to fill the reservoir. The top probe shuts off the water control valve when the water level reaches the proper height. A self-contained control panel with an electronic controller mounted within constantly monitors the humidifier cycle for efficient operation. The electronic controller also provides LED indicators to indicate the status of the humidifier. High efficiency immersion water heaters heat the water to provide steam. An accumulative timed drain cycle performs automatic draining and flushing, thus reducing mineral buildup within the reservoir.

All this is contained within an aesthetically pleasing cabinet that is constructed of 18-gauge steel with a baked enamel paint finish. The cabinet floor is designed as a drain pan with plumbing connections for drain piping. The cabinet is designed to be compact for easy installation and maintenance. The internal stainless steel evaporating chamber is mounted on slides for easy removal. The electrical compartment is isolated from the evaporating chamber and is supplied with a key-locked door.

When it comes to installation, you have a choice with the "EC" Series Electric Humidifier. The humidifier can be wall-mounted with a simple flexible hose connecting the unit to the stainless steel injection tube inserted through the duct wall. You can also mount the unit on the wall with the optional Blower Pack for direct room humidification. The Blower Pack can be mounted directly on top of the "EC" humidifier or mounted remotely, and contains an adjustable speed fan to disperse the steam directly into the space without the use of ductwork.

Insty-Pac or Fast-Pac dispersion grids can be provided to custom fit any built-up or manufactured air handling system.

The versatility of the "EC" Series Electric Humidifier will allow you to design them into any system simply, efficiently, and reliably. Capacities range up to 102 lbs/hr.

NOTE: Also available is the "ECDDR" Series Electric Humidifier which is designed for use with deionized, demineralized, or reverse osmosis water. It is designed for corrosive water that will not conduct electricity. Since mineral buildup does not occur with pure water, there is no need for an automatic drain system or cleaning. These units are practically maintenance-free.

EC-5	EC-10	EC-15	EC-20	EC-25	EC-35
15 lbs/hr	30 lbs/hr	45 lbs/hr	60 lbs/hr	75 lbs/hr	102 lbs/hr
(6.8 kg/hr)	(13.6 kg/hr)	(20.4 kg/hr)	(27.2 kg/hr)	(34.0 kg/hr)	(46.3 kg/hr)

Our results are comforting



Capacities & Weights **Electrical Specifications**

Sheet No.

EC-2

Capacity & Weights "EC" Series

Standard Water Unit Model No.	Steam Outpo	ut Capacity †	En	Humidifienpty	er Weight Full		
	lbs/hr	kg/hr	lbs	kg	lbs	kg	
EC-5	15.0	6.8	139.0	63.1	223.0	101.2	
EC-10	30.0	13.6	140.0	63.5	224.0	101.6	
EC-15	45.0	20.4	141.0	64.0	225.0	102.1	
EC-20	60.0	27.2	142.0	64.4	226.0	102.5	
EC-25	75.0	34.0	143.0	64.9	227.0	103.0	
EC-35	102.0	46.3	146.0	66.2	230.0	104.3	

Electrical Specifications *"EC" Series*

Standard Water Unit Model No.		Single Phase Amperage						Three Phase Amperage					Control
	ĸw	No. of Heaters	120V	208V	240V	480V	600V	No. of Heaters	208V	240V	480V	600V	Circuit Voltage
EC-5	5	Single	41.7*	24.0	20.8	10.4	8.3	Triple	13.9	12.0	6.0	4.8	24 vac
EC-10	10	Double			41.7	20.8	16.7	Triple	27.8	24.1	12.0	9.6	24 vac
EC-15	15	Triple				31.3	25.0	Triple	41.7	36.1	18.1	14.4	24 vac
EC-20	20	Triple				41.7	33.3	Triple			24.1	19.2	24 vac
EC-25	25	Triple					41.7	Triple			30.1	24.1	24 vac
EC-35	34	Triple						Triple			40.9	32.7	24 vac

^{*} EC-5 at 120/1 requires 3 heating elements.


[†] The above capacities are based on 100% efficiency. Actual humidifier capacity may vary due to the heat loss from the humidifier reservoir. The ambient air temperature, air velocity, and injection tube system will affect the rate of heat loss from the humidifier reservoir.




Dimensions & Layout "EC" Series

Sheet No.


EC-3





FRONT VIEW

RIGHT SIDE VIEW



BOTTOM VIEW


Note: Dimensions are typical for all EC models.



Humidifier Layout "EC" Series

Sheet No.

EC-4



Humidifier Features

- SCR modulating control
- Visible status and diagnostic LED indicator lights
- Electronic water level control system
- Accumulative automatic timed drain system
- Seasonal end-of-use drain system*
- High-efficiency incoloy immersion water heaters
- 18-gauge steel cabinet with baked enamel paint finish
- Internal stainless steel evaporating reservoir mounted on slides for easy removal


- Key-locked doors for both reservoir and electrical access
- Easy and simple installation options
- Dispersion methods include Insty-Pac*, Fast-Pac*, injection tube with hose*, or Blower Pack assembly* for room distribution
- Manual reset over-temperature safety switch
- INTAC® microprocessor control system*
- VAV dual modulating control system*



Dispersion Method "EC" Series


Sheet No.

EC-5




Injection Tube and Flexible Hose

Allows remote mounting of the humidifier reservoir from the duct. Also allows the humidifier to be located below a wall-mounted duct.



Insty-Pac and Fast-Pac Multiple Injection Tube Assemblies

For applications where you need a short dissipation distance. Allows remote mounting of the humidifier reservoir from the duct. Also allows the humidifier to be located below a wall-mounted duct.



Blower Pack for Direct Room Humidification

Allows humidifier to be mounted directly on the wall within the space to be humidified.




Blower Pack

"EC" Series

Sheet No.

Optional Blower Pack

In applications where a ducted air system is not available, PURE offers the optional Blower Pack. The Blower Pack contains a two-speed adjustable blower that moves the air over the steam discharge outlet and disperses the steam directly into the space (see Fig. 1). The Blower Pack mounts directly on top of the "EC" humidifier or can be mounted remotely (see Fig. 2).




Locating Blower Pack

The distance that visible steam will travel after leaving the Blower Pack is dependent upon the relative humidity in the room and the capacity of the humidifier. If this visible steam comes in contact with any solid object (walls, beams, machinery, etc.) it may form condensate and drip. Refer to Fig. 3 and Table 4 (Table 4 is located on page EC-7) for data on visible steam travel. This will aid you in planning the location of the Blower Pack.

Remote Mounting

The Blower Pack may be remote mounted up to ten feet away from the "EC" wall mount humidifier (see Fig. 2).



Visible Rise and Throw Fig. 3

Remote Mounted Blower Pack Fig. 2



Blower Pack "EC" Series

Sheet No.

EC-7

Locating Blower Pack

The distance that visible steam will travel after leaving the Blower Pack is dependent upon the relative humidity in the room and the capacity of the humidifier. If this visible steam comes in contact with any solid object (walls, beams, machinery, etc.) it may form condensate and drip. Refer to Fig. 3 (Fig. 3 is located on page EC-6) and Table 4 for data on visible steam travel. This will aid you in planning the location of the Blower Pack.

Table 4


Visible Steam Rise & Throw		Humidifier Model									
		EC-5	EC-10	EC-15	EC-20	EC-25	EC-35				
50% RH	Rise (ft)	1' 2'		3'	4'	5.5'	8'				
	Throw (ft)	8'	10'	13'	16'	18'	23'				
60% RH	Rise (ft)	2'	3'	4'	5'	6'	8'				
	Throw (ft)	13'	14'	16'	18'	20'	25'				

Throw is the horizontal distance the visible steam travels from the steam discharge.

Rise is the vertical distance the visible steam travels from the steam discharge.

Objects in the direct line of the visible steam or objects that are cooler than the ambient temperature may accumulate condensation.

Note: Data above based on 70°F room temperature.



Optional Blower Pack Dimensions Fig. 5

Blower Pack weight is 60 lbs (27.2 kg) * Blower requires a separate 120/1 circuit (by others)



Options "EC" Series

Sheet No

EC-9

Humidifier

Insulation. Unit shall be covered (except top cover) with 3/4" (1.9 cm) thick fiberglass duct insulation. Insulation material shall have aluminum foil facing.

Standby Water Temperature Sensing. Consists of a temperature sensor to maintain water temperature at a selected level for fast response upon a call for humidity.

Modulating Fill. For applications that require RH staying above a minimum threshold, a smaller fluctuation allows you to set the set point lower. Not only does this create a cost savings, but also saves on energy and water usage, making it a more economical option than the constant overfill method. Field-retrofittable on units that use our Tri-Probe water sensor. Requires INTAC® microprocessor option.

Injection Tubes

Injection Tube(s) and Flexible Hose. Each unit shall include one or more 10-foot (305 cm) sections of $1\frac{1}{2}$ " (3.8 cm) I.D. flexible hose and a $1\frac{1}{2}$ " (3.8 cm) O.D. stainless steel injection tube long enough to extend across the duct. Steam ports shall direct steam upward into the airflow. The reservoir cover shall have a matching connection so the flexible hose can be connected with two stainless steel hose clamps. A two-piece duct plate shall be provided to seal the duct opening.

Fast-Pac Multiple Tube Assembly. Tube assembly consists of a stainless steel supply/condensate header with a 3/4"-NPT drain connection and horizontal $1\frac{1}{2}$ "Ø stainless steel injection tubes.

Insty-Pac Tube Assembly. Tube assembly consists of a steam supply/separator header constructed of stainless steel with steam inlet, condensate drain outlet, and steam jacketed injection tubes welded to header. Steam jacketed injection tubes constructed of stainless steel with punched steam ports of the proper size and spacing to deliver the maximum specified capacity.

High Efficiency Insulated Tubes. Thermoplastic wrap reduces condensate loss and unwanted heat gain during cooling mode.

Blower Pack. Unit shall allow for direct space humidification without the use of ductwork. Unit shall be contained within a cabinet that is constructed of 18-gauge steel with a baked enamel paint finish. Unit shall have a two-speed field adjustable fan. The fan is controlled by a thermostat interlock mounted on the steam distributor, it shall activate the fan before steam is discharged and deactivate the fan after all residual steam has been discharged. The blower shall be designed to mount directly on top of the "EC" humidifier or remote wall mounting.

Controls and Safety Devices

VAV Control. A dual input, single output humidistat shall be supplied to provide a single modulating output signal to the humidifier control cabinet. The humidistat shall allow the use of a modulating wall mount sensor and modulating duct high-limit sensor (optional) to control critical variable air volume (VAV) air handling systems. The system shall automatically determine which of the two modulating signals is dominant and slowly reduces the humidifier output capacity, thus preventing over-saturation of the VAV system.

Outdoor Air Temperature Setback. Provides automatic reduction of RH set point to prevent condensation on windows during extreme cold weather.

Airflow Proving Switch. A diaphragm operated airflow proving switch with adjustable control range of .05" W.C. to 12.0" W.C. shall be provided for field installation. Switch rating shall be 2.5 amps at 120V.

Duct High-Limit. A high-limit humidistat shall be provided for duct installation. The high-limit shall be field set to prevent over saturation within the supply duct.

Miscellaneous Accessories

DCT-927 Drain Tempering Kit. Provides cold water mixing of the 212°F drain water.

Condensate Pump. Used to lift condensate from the humidifier or tube assembly.

Seasonal "End of Use" Humidifier Drain. The humidifier will automatically drain the reservoir after a non-use time period which is field adjustable. Upon receiving a call for humidity, the system automatically refills the reservoir and allows the humidifier to operate in "Normal Mode".

INTAC[®] **Microprocessor Controller.** The controller shall be factory-mounted and wired on the electrical compartment door. The INTAC[®] shall provide 16-character digital display of all functions, high/low humidity deviation alarms, time to service shall be capable of *flash memory upgrades* through EIA-485 terminal connections. Software updates shall be capable of being provided to customer via e-mail or Internet.

Communications Gateway. Allows Modbus to communicate with BACnet or LonWorks networks. Gateway can be used concurrently as a cloud connected device for secure remote access for diagnostics, monitoring, alarming and configuration of humidfier in the field. Wi-Fi connectivity can be enabled if desired. Must be used in conjunction with INTAC® microprocessor.



Specification Sample "EC" Series

Sheet No.

EC-8

Humidifier

- 1. The humidifier shall be an electrically heated immersion heater type as manufactured by PURE Humidifier Co. of Chaska, Minnesota.
- 2. The humidifier shall be tested and approved by ETL/ETL-C Testing Laboratories, Inc.
- 3. The humidifier shall have an evaporating reservoir with a gasket sealed cover which is capable of operating at pressures of at least 19"-48 cm (W.C.) without steam or water leaks. The reservoir shall be made of type 304L stainless steel with welded joints. Reservoir shall be mounted on slide rails for easy removal from the cabinet.
- 4. The reservoir shall be contained within a cabinet that is constructed of 18-gauge steel with a baked enamel finish. The cabinet floor shall be designed as a drain pan with plumbing connections for drain piping.
- A surface water flusher shall be included to drain away a portion of the water upon each refill cycle. This is to allow mineral deposits produced by earlier evaporation cycles to be removed.
- 6. The immersion heater(s) shall be incoloy clad and designed for 80 watts per sq. inch. They shall be attached to the reservoir cover and be easily removed for cleaning and inspection. Expansion and contraction of the heater(s) sheath allows mineral buildup to flake off.
- 7. A solenoid-operated water fill valve with internal strainer shall be factory mounted on the cover of the humidifier reservoir. A bottom fill system shall be utilized to prevent any collapse of the steam head during the fill process. The fill valve shall be located to allow a minimum water gap of 1½" (3.81 cm).
- 8. The humidifier shall have a manual reset overtemperature switch factory installed on the humidifier reservoir. The temperature switch shall provide humidifier over-temperature protection.

9. A solid state, plug-in type control module shall be f actory mounted within the control panel and shall electronically control the automatic refilling, low water cut-off, high water cut-off, manual surface water flushing, and safety switch interlock functions. The module shall include automatic drain functions to drain the reservoir. The drain period will be field adjustable in 10-hour increments from 10 to 150 hours with the drain duration adjustable in 2-minute increments between 2 and 30 minutes. During the drain period, the humidifier chamber will drain, and the fill valve will be energized to provide a thorough After the drain period is rinsing action. completed, the drain valve will close, and the humidifier will refill to provide humidity on demand.

The control module shall incorporate LED lights to indicate Seasonal Drain, Safety Circuit Open, Power, Fill Valve Open, Water Level Full, Cool Down Cycle, Drain Valve Open and Heater Energized. The control module shall control all water level control functions through a Tri-Probe sensor mounted on the cover of the humidifier reservoir. The Tri-Probe sensor with stainless steel shield shall electrically sense the water level within the reservoir.

- 10. SCR Modulation, 100% solid state power controller shall be provided in the control panel. The SCR power controller will modulate the humidifier between 0-100% of its rated capacity according to humidistat demand.
- 11. The electrical compartment shall be isolated and watertight from the reservoir compartment. The electrical compartment shall be accessible by a hinged and key locked door. The panel shall include a factory wired sub-panel with a magnetic contactor, Tri-Probe water level control module, fused control circuit transformer, numbered terminal block and heater fuses. The high voltage wiring shall be shielded to prevent shock hazard. The modulating control voltage shall be field adjustable to match the controlling input signal.
- 12. The humidifier shall be supplied with a wall mount channel bracket for easy wall mounting. The bracket shall be load tested to a 600-pound capacity.